ELFTM 3200 v02.05.01

Digital Energy, Power and V, A, F Meters



Brilliant Single line 4 digit (digit height 14.2 mm) display
 Kilo, Mega and Negative (-) indicator

- · Auto scaling capability for Kilo, Mega, and Giga.
- 3 smart keys for easy and intuitive navigation Password protection on setup parameters
- True RMS values are measured with update every 1 sec
 The energy values are not lost even after INTG is cleared and can be viewed with OLD parameter.

Index

Topic	Refer Section
For help - Contact us	1.1
Safety Tips	1.2
Model wise features - ELF 3200 Series	1.3
Technical Specification	1.4
Key pad operation	2.1
Auto Scroll	2.2
Indicators - Kilo, Mega, Giga, negative	2.3
What's this - RMS, INTG, OLD	2.4
What's this - W, W.H, W.h, DIAG	2.5
PROG Menu - Setup	3.1
Enter PROG Menu to edit set parameters	3.2
Enter PROG Menu - Read Only	3.3
Enter PROG Menu - while powering ON	3.4
Mechanical Dimensions	3.5
Electrical & Mechanical Installation	4.1
Wiring diagrams	4.2
Recommended Panel cut-out	4.3
Energy Integrator - INTG	5.1
Labelling of INTG parameters	5.2
Viewing INTG parameters	5.3
OLD data register	5.4
INTG Overflow	5.5
What's this - SET, CLR, PROG, RUN	5.6
Display Map - ELF 3234	6.1
Display Map - ELF 3234-3	6.2
Display Map - ELF 3259	6.3
PROG Menu - Setup parameters	7.1
Edit set parameters	7.2
INTG CLear	8.1
Warranty and Calibration	0.0

1.1 Need Help? We are here

Warranty and Calibration

- Check our website www.conzerv.com for the latest Help, FAQs or our Help Desk phone number for support.
- Ouestion persists? Then send us an email to support@conzerv.com
- Remember to include Model
- Serial number
- Description of problem, settings, wiring diagram

1.2 Safety first

- · Only qualified and trained personnel should carry out
- Installation & wiring
- Disconnection & removal of the meter De-energize the connected circuits before meter installation or
- disconnection. • During normal operation of this meter, hazardous voltages might be present at the rear terminals, which can cause severe injury or death. High voltages are likely to be present inside even after the meter has been
- Do not open the cover of the meter there are no user serviceable parts
- · Contact your nearest authorized Conzerv service center for all your servicing requirements.

1.3 Model wise features

					v02.0	05.01			
Parameter		ELF ELF 3234					ELF 3234-3		
		3259	W	VA	VAR	PF	W	VA	VAR
RMS AVG L1 L2 L3	V								
	Α								
	% Load								
	% Unbal	0							
	F								
	RPM								
RMS Total L1 L2 L3	W		0				0		
	VA			0				0	
	VAR				0				0
	PF					0	0	0	0
INTG 3 Ph energy	Wh		0				0		
	VAh			0				0	
	VARh				0				0
	-VARh				0				0
OLD 3 Ph energy	Wh		0				0		
	VAh			0				0	
	VARh				0				0
	-VARh				0				0

Display parameter factory-set to W for ELF 3234 Wh for ELF 3234-3. Display parameter selection can be edited through PROG Menu. Refer section 7.1. 7.2

2.1 Keypad Operation

Take a quick look at what the keys do Navigation Concept CODE PROG RUN SET **VLL** V12 **RMS VLN**

Let us take an example to understand the actions of the front panel keys in the RUN menu. This example will explain how you can navigate from the 'RMS' page to the 'VLN' page and back to 'RMS' in ELF 3259

Step 1: • From the RMS page use the RIGHT key . The display shows 'VLL'.

• The RIGHT key can be used to go forward into sub-parameter pages. Step 2: • Now press the DOWN key

• You can Scroll down through other display pages at the same level using the DOWN key. The display shows 'VLN'. Congrats you have successfully navigated from 'RMS' to 'VLN'

Step 3: • To return to 'RMS' press the LEFT key. The display shows 'RMS' • Using the left key you can go back towards to the main parameter pages from the sub-parameter pages • Going Left past "PROG" requires Code entry to enter PROG menu

(Setup and Clear)

2.2 Auto Scroll

- Auto display of a group of Display Pages sequentially every 5 seconds, without constantly pressing the keys.
- Parameter Name (1 sec) followed by the value (4 sec) is displayed. **Enter Auto Scroll**
- Go to the desired display page
- Press v for 3 seconds (minimum) and then release key.
- The display flashes "AUTO" and then automatically scrolls through other pages at the same level.
- Press any key to revert to Manual Scrolling.

2.3 Indicators - Kilo, Mega, Giga and Negative



When lit, indicates that the reading is in Kilo (10³). 10,000 is displayed as 10.00K and 1.0K as

E.g.: 32.00 with K LED glowing indicates the value reads 32,000



When lit, indicates that the reading is in Mega, (10⁶). 10,000K is shown as 10.00M and 1.0M as 1000K E.g.: 32.00 with M LED glowing indicates the value reads 32,000K

When Kilo and Mega are both glowing, the reading is in Giga (10⁹). 10,000 M is shown as 10.00G. 1.0G is shown as 1000M. E.g.: 32.00 with both K and M LED's

Negative -

When lit, indicates that the reading is **negative** Per IEEE 100 and industry standard practice by meter-men:

glowing reads as 32,000M

 With Forward Flow of Watts & Capacitive (Leading) load: VAR & PF are negative.

• With Reverse Flow of Watts & Inductive (Lagging) load: VAR, PF and Watts are negative E.g.: 32.00 with negative LED glowing indicates the value reads as -32.00.

2.4 RMS, INTG, OLD



RMS: The RMS block comprises of instantaneous readings.

Refer Section 1.3 for RMS parameters measured by each ELF model

INTG: Energy Integrator, which provides several parameters for Energy Management. Refer Section 5.1



Stores the energy values from INTG NOTE when INTG is cleared (manually or overflow

Refer Section 5.4

2.5 w, w.h, w.h, DIAG



Indicates watts (both total and phasewise values can be viewed).

Refer Section 6.1, 6.2, 6.3

1.4 Technical Specification

Sensing / Measurement	True RMS, 1sec update time				
Input Voltage	4 voltage input terminals (V1, 2, V3, VN) 80 to 500 Vac Line - Line				
Input Current	Current input terminals (A1, A2, A3) 50mA to 6A (Field configurable 1A or 5A) Overload: 10A max continuous, 50A max for 3 sec				
Aux Supply (Control Power)	80 to 270 Vac				
Burden	0.2 VA max per volts / amps input 3 VA max on Aux Supply				
Frequency	45 to 65 Hz				
Resolution	RMS 4 digit, INTG 8 digit				
Environmental	Operating Temperature: -10°C to 60°C				
	Storage Temperature: -25°C to 70°C Humidity 5% to 95% non-condensing				
Weight	225 gms approx				

The first four digits of energy value (W.h.) are labeled with "W.H' (both uppercase).

Refer Section 5.2, 5.3



The last four digits of energy value (W.h.) are labeled with "W.h" (h lowercase). Refer Section 5.2, 5.3

Represents diagnostic pages. Scroll right to view the diagnostic values (these values are useful for factory testing only). Refer Section 6.1, 6.2, 6.3

3.1 PROG Menu - Setup

PROG menu gives the complete list of user-programmable parameters. • The meter must be set (programmed/configured) to match the application

settings, before use. Otherwise, the readings will be wrong. · All the Setup values can be re-programmed at any time, upon entering


"SET". However, the settings: SYS (Star/wye or Delta), Vpri, Vsec, Apri, Asec critically determine the scaling of measured readings. • While the scaling may be used to minimise the error in readings due to Instrument Transformer errors, wrong settings will upset the readings of

CAUTION: It is the user's responsibility to ensure that only qualified personnel correctly Setup the Meter.

You can enter PROG menu in

• Edit mode - to view or edit set parameters - Section 3.2 • View only mode - to view the set parameters - Section 3.3

3.2 Enter PROG Menu in edit mode



Step 1: • Go ◀ . The display will show "CODE Y" with the "Y" blinking.

Step 2: • To continue with code entry scroll left using the LEFT key ◀

Step 3: • Press • 3 times. The blinking zero will shift position one place leftwards with each key press

Step 4: • Now 2 starts blinking. • Press v to change the blinking 2 to 1.

• You have now entered the factory set code 1000

Step 5: • Press ◀ to confirm the code. • The display shows "PASS" and then "RUN". • "PASS" indicates that you have successfully entered the code and

entered PROG Menu - Setup. If the display shows "FAIL" - means that you have not successfully entered

PROG Menu, don't despair. Try again from step1. Restart the meter to easily return to the RMS page to re-enter the code.

3.3 Enter PROG Menu in View (read-only) mode



Step 1: • Go ◀ . The display will show "CODE Y" with the "Y" blinking. Step 2: • Go. The display will show "CODE N" with the "N" blinking

Step 3: • Go ◀ , to continue with PROG menu entry in view mode. Step 4: • The display shows "FAIL" and then "RUN".

• You have successfully entered the PROG Menu - Setup in view

mode. Step 5: • Press , display shows CLR.

• Press again, display shows SET.

• You are at the PROG Menu now. Press to enter the menu and view the set parameters.

• You cannot go left into the PROG menu ("RUN") unless you enter a code • Once in the PROG menu ("RUN"), you can go down to "CLR" or "SET". Going right though the "CLR" page allows you to clear the integrator. Similarly, keep going right through "SET" to program the meter settings. When done:

Go Left all the way back to the PROG menu

Go Up to "RUN"

Go Right into RMS to view the display pages again. Complete PROG Menu listing all the set up parameters is shown overleaf in Section 7.1

• During power ON, press the key for 2 sec continuously

• Press withe key to enter the PROG menu.

Edit the setup parameters as explained in section 7.2

1. To set the meter settings, you must first enter the PROG Menu. $\,$ 2. Go Up to "PROG", then Left to enter the PROG Menu.

You must now enter the Factory Set code of 1000, to proceed. "Code y", followed by the entry of the Code "1000" is required.

To enter the code, edit the blinking digit value up or Down to get

"1000"

can't change them.

CON/ERV Aux Supply LOAD

Direct Voltage Connections if Voltages are less than 501v ac L-L. Otherwise

The unused current terminals must be shorted together.

1.) Program the meter in for STAR mode. However Voltage primary and secondary needs to be programmed as Line to Line. 2.) Connect the voltage and current inputs only to the V1 and A1 voltage and


current terminals of the meter.
3.) The unused current terminals (A2 and A3) must be shorted together to

reduce noise picked up in the meter 4.) However, the energy parameter readings will be accurate.



4.3 Recommended Panel Cut-out

Single phase connection



3 Phase 4 Wire Star (Wye) 3 CTs. Direct Voltage Connections if Voltages are less than 501V ac L-L. Otherwise 3 PTs N L3 L2 L1 LINE | | | CON/ERV S11 S11 S1

Current Rating

Or 16 AWG minimum

> 0.1 A

> 7.5 A

* Other Instruments In series

S 1

4.1 Electrical & Mechanical Installation

Insulation Rating

Power Driver preferred or hand screw driver

Shaft diameter < 5mm. Diameter = 5mm or more will get stuck in the safety

Tightening Torque: (25 to 60) N-cm

Loosening Torque: (55 to 60) N-cm

the Safety Cover.

Screw Travel 6mm less wire thickness

4.2 Wiring Diagrams

Philips tip preferred or flat tip. DO NOT USE POZIDRIV TIP

Torque greater than 60 N-cm may strip the screw or break

> 500 V ac

> 500 V ac

M O

• Connecting cable requirements

Voltage Circuit

Current Circuit

Driver


Screw head diameter

Torque

LOAD

Tip

• Tools & Equipments



Note: Remember to make sure Delta is programmed in the meter Setup. Leave the Vn terminal un-connected 2 Phase 3 Wire, 110-0-110V connection diagram (U.S.)

L2 N L1

S11 S2 S2 Aux Supply Other Instruments in series LOAD 110V 0V 110V

3.4 Enter PROG Menu on Power ON

An easy way to enter PROG Menu

Meter displays SET.

Keep going left.

Without entering the code, you may view the settings, but you

3.5 Mechanical Dimensions



